

The installation video below is a comprehensive installation procedure for fitting the ASR valve flap controller to your **GLC 63 or GLC43 Facelift or Prefacelift**

Please note: The driver side connection is critical. As pointed out in the video the ASR cable must be connected directly to the valve motor NOT the small extension cable. If an incorrect connection is made there may be error codes and a loss of power. The small extension cable comes off the valve to a coupling. Disconnect at the Valve motor

If possible this should be done with the car on a hoist or ramp to make installation easier

<https://www.youtube.com/watch?v=63ltihnlwt4>